
S1 80 Mount RCD BB/TXF Cam Drive

Mounting bolt holes must be drilled.
Bolt pattern is indicted on cover with drill points to allow clocking of pump.
All configurations available.
Requires appropriate thrust bushing from RCD.



Mount Configurations
All AVIAID Mounts are
integral to pump. No
adapters are required.
Separators are .16" or
.25" wide. Mount drawings
are full size. "Xxxx" indicates
hex size in 1/16ths. "xXxx"
indicates separator width (1
= .16", 2 = .25", 5 = .50".
"xxXX" indicates Mount #.

