

S1 68 Small Plate Pump Mount  
with Register - Revised

Mount Configurations  
All AVIAID Mounts are  
integral to pump. No  
adapters are required.  
Separators are .16" or  
.25" wide. Mount drawings  
are full size. "Xxx" indicates  
hex size in 1/16ths. "xXxx"  
indicates separator width (1  
= .16", 2 = .25", 5 = .50").  
"xxXX" indicates Mount #.

