Mount Configurations
All AVIAID Mounts are integral to pump. No adapters are required.
Separators are .16" or .25" wide. Mount drawings are full size. "Xxxx" indicates hex size in 1/16ths. "xXxx" indicates separator width (1 = .16", 2 = .25", 5 = .50". "xxXX" indicates Mount #.



