

S1 84 Mount
RCD/MSD Taper Clamp

Mount Configurations
All AVIAID Mounts are integral to pump. No adapters are required. Separators are .16" or .25" wide. Mount drawings are full size. "Xxxx" indicates hex size in 1/16ths. "xXxx" indicates separator width (1 = .16", 2 = .25", 5 = .50"). "xxXX" indicates Mount #.

